

NuVIEW Installation Instructions

Installation of Navitar Nuview Series 499 lens on Sony FX-30 & FX35 Projectors.

TOOLS REQUIRED: Phillips Head Screwdriver

Disassembly:

1. Center lens using the Lens Shift function.
2. Turn off projector and unplug the AC power cord.
3. Remove 2 screws on front cover.
4. Loosen 4 screws that attach lens and mount to projector.
5. Remove 4 screws and washer that attach mount to projector.
6. Use caution not to drop the lens.

Installation:

1. Remove NuView lens from mount by rotating and unscrewing the lens.
2. Place 4 screws and washer on mount (note washers are on opposite side in pocket than screw head).
3. Place lens mount into the projector and secure 4 screws
4. Install the NuView lens into the lens mount by screwing the lens in.
5. Replace front cover and secure with 2 screws removed previously.
6. Focus as needed by either rotating the entire lens clockwise or counterclockwise.
7. If you are using the 499MCL1625, focus by rotating gently CW or CCW. Move the projector location to change the zoom.
8. If you are using the 499MCZ500 or 499MCZ900, to focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring and re-tighten the thumbscrew.

CAUTION: When focusing, the 499MCZ500 and 499MCZ900 be sure not to twist lens completely out of the adapter!

REV 122812 CAL

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com