

NuVIEW Installation Instructions

Installation of Navitar NuView Series 498 lens on Panasonic PT-EZ570 , EW530, EW630, EX500 & EX600 Projectors.

TOOLS REQUIRED: None

Disassembly:

1. Center lens using the Lens Shift function.
2. Turn off projector and unplug the AC power cord.
3. While pressing the "Lens release" Button on the top of the cabinet, turn the lens counter clockwise until it stops and pull it out slowly from the projector.
4. Use caution not to drop the lens.

Installation:

1. Remove NuView lens from mount but rotating and unscrewing the lens.
2. Place lens mount into the projector, ensuring that the notch is to the left of top center.
3. Once the mount drops into place, rotate it clockwise until the mount is securely attached to the projector.
4. Install the NuView lens into the lens mount by screwing the lens in.
5. Focus as needed by either rotating the entire lens clockwise or counterclockwise.
6. If you are using the 495MCL1625 or the MCL900, focus by rotating gently CW or CCW. Move the projector location to change the zoom.
7. If you are using the 498MCZ500, to focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring and re-tighten the thumbscrew.

CAUTION: When focusing, the 498MCZ500 and 498MCL1625 be sure not to twist lens completely out of the adapter!

REV 012213 CAL

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com