

NuVIEW Installation Instructions

Installation of Navitar Series 861 lens on EPSON POWER LITE Z8000 Projectors.

TOOLS REQUIRED: Phillips Head Screwdriver

Disassembly:

1. Center lens using the Lens Shift function.
2. Turn off projector and unplug the AC power cord.
3. Loosen screw covering the inputs cover and remove cover.
4. Loosen 3 screws and remove the front cover over the lens.
5. Remove manufacturer lens by turning bayonet clip on top of lens mount counterclockwise.
6. Use caution not to drop the lens.

Installation:

1. Remove NuView lens from mount by rotating and unscrewing the lens.
2. Place lens mount into the projector, placing the locating pin on the projector in the locating hole on the lens mount, and secure with bayonet clip.
3. Install the NuView lens into the lens mount by screwing the lens in.
4. Focus as needed by either rotating the entire lens clockwise or counterclockwise.
5. Replace front cover and secure with 3 screws loosened previously.
6. If you are using the 861MCL2125, focus by rotating gently CW or CCW. Move the projector location to change the zoom.
7. If you are using the 861MCZ729 or 861MCZ151, to focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring and re-tighten the thumbscrew.

CAUTION: When focusing be sure not to twist lens completely out of the adapter!

REV 08/18/11 MLD

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com