

## NuVIEW Installation Instructions

### Navitar/NuView Series 869 lens on Christie LW650

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER, M3 HEX HEAD SCREWDRIVER

- 1) Disconnect unit from power source.
- 2) Remove faceplate by turning faceplate counterclockwise.
- 3) Remove Cover by tipping cover up and pulling toward you.
- 4) If Prime Lens is not installed skip to step 5. Remove prime lens by rotating lever to the left. Remove Christie adapter plate from lens by removing 4 Socket Head Cap Screws with M3 Hex Head Screwdriver.
- 5) Remove Navitar/NuView Lens from adapter plate, and install Navitar adapter plate to the Hitachi adapter plate with the 4 supplied Phillips head screws and washers.
- 6) Install the 2 adapter plates into the projector, secure by rotating lever to the right.
- 7) Install Navitar/NuView lens by twisting lens into adapter.
- 8) Install Cover.
- 9) Install faceplate
- 10) Plug in projector and focus lens by twisting the lens in either direction until image is in focus.

Navitar, Inc.  
200 Commerce Drive  
Rochester, New York  
14623

Phone  
585.359.4000  
800.828.6778

Fax  
585.359.4999

[navitar.com](http://navitar.com)  
[info@navitar.com](mailto:info@navitar.com)