

5φ MOTOR AND HALL EFFECT CABLE INFORMATION:

- ZOOM / FOCUS / HE CABLE LENGTH = 0.15m
- USE NAVITAR #1-40170 TO CONNECT TO 5φ NAVITAR CONTROLLERS (1-40167, 1-40168, 1-40169)

ZOOM / FINE FOCUS MOTOR
5 POSITION FEMALE
CONNECTOR
(MOLEX #50-57-9405)

HALL EFFECT SENSOR
4 POSITION FEMALE
CONNECTOR
(MOLEX #50-57-9404)





5φ ZOOM / FINE FOCUS MOTOR PINOUT

- PIN 1 = MOTOR 1 (BLUE)
- PIN 2 = MOTOR 2 (RED)
- PIN 3 = MOTOR 3 (ORANGE)
- PIN 4 = MOTOR 4 (GREEN)
- PIN 5 = MOTOR 5 (BLACK)

4 PIN HE SENSOR PINOUT

- PIN 1 = COMMON
- PIN 2 = FAR LIMIT
- PIN 3 = +5VDC
- PIN 4 = NEAR LIMIT

OUTLINE

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES AND INCLUDE CHEMICALLY APPLIED OR PLATED FINISHES		PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF NAVITAR. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF NAVITAR IS PROHIBITED.		
SCALE:	1:1	 ROCHESTER, NEW YORK		
WEIGHT:	1.59 lbmass			
DR BY:	BONAFEDE	MTR 12X ZM, 5φ 20:1, HE, w/12mm FF		
CH BY:	R. PODLENA			
PROJECT #:	E3192	1-52004		
DATE DR:	3/21/2014			
DO NOT SCALE DRAWING		SIZE C	SHEET 2 OF 2	REV A